

BARBEQUE INSTRUCTIONS:**PLEASE NOTE:**

***THIS BBQ IS EQUIPPED WITH AN AUTOMATIC FIRE SUPPRESSION SYSTEM.**

***THE DOOR NEEDS TO BE FULLY OPEN AND THE EXHAUST FANS NEED TO BE ON FOR THE GAS TO FLOW.**

1. Unlock padlocks (Key 2310) at the bottom of the left and right side of the overhead door and pull the locking lever inwards.
2. Raise the overhead door by pulling on the chains on the right side of the door and hook the chains in the clasp.
3. **DOOR MUST BE FULLY OPEN FOR THE BBQ TO OPERATE.**
4. Check and make sure all gas control knobs are set to **OFF**. Horizontal position for grills/ griddles and vertical position for 4 open-burner top range.
5. Open main gas valve (Key 2105) on the outside of the west wall of the BBQ enclosure.
6. **TURN ON THE EXHAUST FANS.** The **GREEN START** button is located in the steel cupboard (Key 2310) on the west wall. Light switches are also located there.
7. To ignite any of the 4 open burners, turn gas knob to pilot and hold in while depressing red igniter button located in cabinet below, then turn gas knob to full **ON**.
8. Select which burners / griddles you wish to use. Turn gas control knob for that unit on and press igniter switch (you will hear a clicking sound until gas ignites). This may continue for a minute or so until ignition. Select other burners / griddle as desired, ignite the same way.
9. When finished, turn all gas control knobs to **OFF**, (horizontal for grills / griddles and vertical for 4 open-top range burners). Turn igniters to **OFF**.
10. Turn **OFF** the exhaust fans and lights. Close and lock cabinet.
11. Close main gas valve on the outside of the west wall of the BBQ enclosure and lock.
12. Close the overhead door with the chains, push the locking levers to the outside and attach the padlocks.

***FOR FACILITY PROBLEMS, PLEASE CALL "9" 403-320-3111**

***IN CASE OF EMERGENCY, DIAL "9" 911**